

Multi-Functional Pet Stroller

Installation & Operation Manual











Please read these instructions carefully before use and keep them for future reference. Your pet's safety maybe affected if you do not follow these instructions.

CARE AND MAINTENANCE

- Please regularly check if there are screws loose, damaged parts or suture breakage, if necessary, replace broken parts
- When disassembling, carefully follow the operating instructions in order to avoid damage than necessary
- When cleaning the cloth on the stroller, brush the stain directly with the brush or other cleaning equipment, for other parts cleaning, please use household soap or neutral detergent.

WARNING: Keep all the plastic bags and small components away from the Child to avoid possible suffocation and injury.

NOTICE: Before assembling and using, check the stroller if there is any damaged hardware, loosen joints, missing parts or sharp edges. DO NOT use if any parts are missing or broken.

PARTS LIST			
A Pet stroller	B Pet basket	C Pads	D The shed
			
1 PC	1 PC	1 PC	1 PC
E The armrest	F Rear wheel	G Positioning card buckle	H Front wheel
			
1 PC	2 PC	2 PC	2 PC

INSTALLATION INTRODUCTION

1.OPEN THE FRAME

Take out the frame,unlock the safety hook. Lift up the push handle until you hear an audible "click" to indicate the frame is locked in open position.



2.FRONT AND REAR WHEELS ASSEMBLY

- (1)Lift up stroller frame front axle tube and push down the metal button.
- (2)Push up until you hear an audible "click" to indicate the front wheel is locked into position.Repeat for the second wheel.
- (3)To fix the direction of the front wheels, align front wheels in a straight forward position and press down the front wheel lock.



Metal button

3.FRONT WHEELS DIRECTION UNIVERSAL AND FIXING

To fix the direction of the front wheels,align front wheels in a straight forward position and press down the front wheel lock,the front wheels can only move straight forward and backward.Lift up the front wheel directin lock,direction of the front wheels can be universal.



Universal rotating



Fixing direction

INSTALLATION INTRODUCTION

4. REAR WHEEL INSTALLATION

- (1) Insert axle of rear wheel into the hole on leg until a sound "click".
- (2) If need disassemble rear wheel, press down the iron button and remove it.



5. REAR WHEELS ONE TOUCH BRAKE

Picture 1: Lift up the rear wheel axle to release the brake, then the stroller can move freely.

Picture 2: The locking status, the stroller unable to move.



Non-braking model



Braking model

INSTALLATION INTRODUCTION

6. OPEN BASKET

- (1) Fix the iron supporting rods as picture.
- (2) Zipper fabric cover.
- (3) Put in pet sleeping mat.



7. BASKET INSTALLATION AND DETACHMENT

- (1) Press down white buttons on both sides of the basket and insert it into stroller frame until a sound "click".
- (2) Fix the hook as picture to make sure basket harshness.
- (3) If need take down the basket, please open the hook first and press down the white button on both sides of the basket to take it down.
- (4) The basket can be put on floor directly and used separately.



FUNCTION INTRODUCTION

8. Open your pet carrier

You can carry the sleeping basket by using the top carrying handle on the top of canopy .



9. Fix pet carrier on car seat

Insert the car safety belt into the two straps on side of pet carrier and fix it, when use pet carrier separately on car seat.



FUNCTION INTRODUCTION

10.Easy folding the stroller in 3 steps

- (1) Slide the second locking key by your thumb and press the other key by fingers at the same time as picture.
- (2) Push down the frame to fold the stroller
- (3) Lock the folding key to prevent the stroller accidentally open



