


# 4 FT CHRISTMAS WREATH WITH BOW


## ASSEMBLY INSTRUCTION

### Parts List




<p>A. 1st wreath</p>	<p>B. 2nd wreath</p>	<p>C. 3rd wreath</p>	<p>D. 4th wreath</p>	<p>E. 5th wreath</p>
<p>F. Left half of Bow</p>	<p>G. Right half of Bow</p>	<p>H. NUT</p>	<p>I. Screw</p>	<p>J. R-PIN</p> <p>K. Cable ties</p>

**STEP 1** Please carefully and slowly unpack the packaging and inspect all components in the following assembly sequence: A-B-B-C.C-D. D-E.E-A.Find the nuts and screws, tighten them separately and link them together in sequence. During the assembly process, be careful not to pinch the male and female connecting wires, align them with joint, and tighten the nuts by connecting them.




## STEP 2

Find components F and G, fix them together with ties, and then tighten the rolling strip, as shown in the following figure.



## STEP 3

There are two holes on the wreath. Insert the two positioning rods behind the bow into the wreath and lock them with R pins to prevent the bow from falling. Finally, connect the male and female connectors and light it up.



## Troubleshooting

Problem	Reason	Solution
Lights do not work	Not plugged in	Firmly plug into wall outlet
	Extension cord does not have power	Plug inturn on extension cord
	Male and female connectors	Check the male and female connections and tighten the plastic nuts